


Parts list directory


1. CTY-E Car body explosion diagram and parts catalog



Map7-1 CTY-E Car body explosion diagram

No.	Part name	QTY	No.	Part name	QTY
101	Hexagon head bolts	4	121	The left rear wheel fork weldment	1
102	Flat washer	6	122	The brake pressure cap	1
103	Flat washer	4	123	Hexagon thin nuts	1
104	Hexagonal nut	4	124	The brake lever	1
105	Car body welding	1	125	The right rear wheel fork weldment	1
106	Pacific washer	6	126	Locking plate	1
107	Hexagon head bolts	6	127	Shaft with elastic ring	8
108	Safety net	1	128	The rear casing	4
109	Hexagonal nut	4	129	After the shaft	2
110	chain screw	2	130	Deep groove ball bearing	8
111	chain	2	131	The rear wheel	2
112	U card	1	132	Elastic cylindrical pin	1
113	Cap nut	2	133	The brake pedal	1
114	Hexagon head bolts	1	134	The brake shaft	1
115	magnet	1	135	Slot length cylindrical side set screws	1
116	Hexagon head bolts	1	136	Shaft with elastic ring	1
117	The rear cover dust cover	1	137	eccentric	1
118	Shaft with elastic ring	1	138	Hex cylinder head screw	1
119	Deep groove ball bearing	2	139	The front wheel	2
120	Single row taper roller bearings	2	140	Front axle	2


1. CTY-E Section 2. Double car explosion diagram and parts catalog



Map7-2 CTY-E Double festival bodywork explosion figure

No.	Part name	QTY	No.	Part name	QTY
101	Hexagonal nut	2	128	The brake lever	1
102	The upper adjusting screw	2	129	The right rear wheel fork weldment	1
103	Cylindrical roller bearing	2	130	Locking plate	1
104	Shaft with elastic ring	3	131	Shaft with elastic ring	8
105	All electric clearance adjustment	4	132	The rear casing	4
106	Car body welding	1	133	After the shaft	2
107	Big flat washer	4	134	Deep groove ball bearing	8
108	Hexagon head bolts	4	135	The rear wheel	2
109	Safety net	1	136	Elastic cylindrical pin	1
110	Hexagonal nut	4	137	The brake pedal	1
111	chain screw	2	138	The brake shaft	1
112	chain	2	139	Slot length cylindrical side set screws	1
113	U card	1	140	Shaft with elastic ring	1
114	Hexagonal nut	4	141	eccentric	1
115	Flat washer	6	142	Hex cylinder head screw	1
116	Cap nut	2	143	The front wheel	2
117	Hexagon head bolts	1	144	Front axle	2
118	The magnet	1	145	Shaft with elastic ring	2
119	Hexagon head bolts	1	146	Idler pulley	2
120	The rear cover dust cover	1	147	Deep groove ball bearing	2
121	Deep groove ball bearing	2	148	Hole with elastic ring	2
122	Single row taper roller bearings	2	149	Allen flat end set screws	4
123	The left rear wheel fork weldment	1	150	Under the post within the connection plate	1
124	Hexagon head bolts	4	151	Flat washer	1
125	Standard spring washer	4	152	Standard spring washer	1
126	The brake pressure cap	1	153	Hex cylinder head screw	1
127	Hexagon thin nuts	1			

2. CTY-E Hoisting frame explosion diagram and parts catalog




Map7-3 **Hoisting frame explosion diagram**

No.	Part name	QTY
201	Check ring	6
202	Fork plate shaft	1
203	Fork welding pieces	2
204	All electric clearance adjustment	4
205	Idler pulley	4
206	Deep groove ball bearing	4
207	Hole with elastic ring	4
208	Hexagonal nut	4
209	Hexagon head bolts	4
210	Lifting frame welding seam	1

Form 7-3 **Hoisting frame parts catalog**

CTY-E Oil pump explosion diagram and parts catalog




Map7-4 CTY-E Oil pump explosion figure

No.	Part name	QTY	No.	Part name	QTY
301	Piston rod	1	335	O sealing ring	2
302	Shaft with elastic ring	2	336	rod	1
303	Deep groove ball bearing	2	337	sheath	1
304	Chain wheel	2	338	O sealing ring	1
305	Hole with elastic ring	2	339	The relief valve adjusting screw	1
306	Sprocket shaft weldment	1	340	The relief valve spring	1
307	Cylinder head	1	341	The relief valve spring	1
308	The piston rod shield	1	342	Steel ball	1
309	O dust ring	1	343	handle	1
310	O sealing ring	1	344	Inner hexagonal screw	1
311	The piston rod sealing ring	1	345	Hand connecting shaft	1
312	Oil plug	1	346	Roller shaft	1
313	Oil pump weldment	1	347	Standard spring washer	1
314	Clamping ring	1	348	Inner hexagonal screw	1
315	Spring cover	1	349	Roller wheel	1
316	Pump core	1	350	Roller cover	1
317	Spring	1	351	Foot pedal set	1
318	Dust ring	1	352	Foot pedal connecting shaft	1
319	Sealing ring	1	353	Elastic pin	1
320	Valve plug	1	354	Foot pedal	1
321	Copper sheet	1	355	Foot rack	1
322	High pressure spring	1	356	Metalloid nut	1
323	Valve core	1	357	Hexagonal nut	1
324	Valve body	1	358	Drop bolt	1
325	O Sealing ring	1	359	chain	1
326	Steel ball	1	360	Pulling rod	1
327	Switch plate	1	361	Elastic pin	1
328	B cotter pin	1	362	Roller handle	1
329	Cotter pin	1	363	Elastic pin	1
330	Hex nut	1	364	Small hand bag glue	1
331	Slotted flat end set screws	1	365	Elastic pin	1
332	Pushing spring	1	366	Return spring	1
333	O sealing ring	1	367	Locate the shell	1
334	Top rod cover	1	368	Elastic pin	1

Form 7-4 CTY-E Pump parts catalog

CTY-E Double oil pump explosion diagram and parts catalog



Map7-5 CTY-E Double oil pump explosion figure

No.	Part name	QTY	No.	Part name	QTY
301	The piston rod	1	337	O ring	1
302	Shaft with elastic ring	2	338	Plunger sleeve	1
303	Deep groove ball bearing	2	339	O ring	2
304	sprocket	2	340	The top bar	1
305	Hole with elastic ring	2	341	sheath	1
306	Hexagon head bolts	1	342	O ring	1
307	Sprocket shaft weldment	1	343	The relief valve adjusting screw	1
308	Flat washer	1	344	The relief valve spring	1
309	Standard spring washer	1	345	Safety seat	1
310	Hexagonal nut	1	346	Steel ball	1
311	Cylinder head	1	347	Grip weldment	1
312	The piston rod shield	1	348	Allen flat end set screws	1
313	O ring	1	349	Hand connecting shaft	1
314	O ring	1	350	Roller shaft	1
315	The piston rod sealing ring	1	351	Standard spring washer	1
316	Oil plug	1	352	Hex cylinder head screw	1
317	Oil pump weldment	1	353	roller	1
318	Compression ring	1	354	Roller set	1
319	Spring gland	1	355	Foot pedal set	1
320	The pump core	1	356	Foot pedal connecting shaft	1
321	The pump core spring	1	357	Elastic cylindrical pin	1
322	Shield pump core	1	358	The pedals	1
323	The pump core sealing ring	1	359	The pedals	1
324	High voltage plug	1	360	Insert nut, not of metal	1
325	Copper gaskets	1	361	Hexagonal nut	1
326	High pressure valve disc spring	1	362	Eyelet bolt	1
327	High pressure valve core	1	363	The chain	1
328	High pressure valve body	1	364	Tie rod	1
329	O ring	1	365	Elastic cylindrical pin	1
330	Steel ball	1	366	Hand wheel	1
331	Switch board	1	367	Elastic cylindrical pin	1
332	Type B pin	1	368	Small hand bag glue	1
333	Cotter pin	1	369	Elastic cylindrical pin	1
334	Hexagonal nut	1	370	Return spring	1
335	Slotted flat end set screws	1	371	Locate the shell	1
336	Plunger spring	1	372	Elastic cylindrical pin	1

Form 7-5 CTY-E Double oil pump parts catalog